
# ETLIN-DANIELS

## INSTALLATION FOR WRA54S-M46W0C-WH LED WRAP AROUND LIGHT FIXTURE / CHANGEABLE WATTAGE AND COLOR TEMPERATURE



## SAVE THESE INSTRUCTIONS - READ ALL INSTRUCTIONS CAREFULLY

## ⚠ WARNING

Intertek 5001780 · 5 YEAR LIMITED WARRANTY/GARANTIE LIMITÉE · CAN ICES-005 (B) / NMB-005 (B)

## PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- To prevent personal injury or product damage only licensed electricians / personnel should install fixture.
- To avoid electric shock or component damage disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the National Electric Code (NEC)/ Canadian Electrical Code (CEC) and all applicable Federal, State/Provincial and Local Electric Codes and Safety Standards.
- Disconnect fixture and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
- To prevent product malfunction and/or electrical shock this product must be properly grounded.
- All parts must be used as indicated in the instructions. Do not substitute any parts, leave parts out, or use any parts that are worn, damaged or broken.
- Selected fixture voltage must match supply line voltage.

## INSTALLATION INSTRUCTION

Figure 1




Figure 2




Figure 3




Figure 4




Figure 5





Figure 6




1. Carefully remove the plug, and remove lens from the luminaire (Fig. 1) bypulling up from edge of lens near the endcap.
2. The LED wrap fixture is compatible out of box for installation with 4" surface JBox with 3.5" mounting hole spacing. Or 3" J Box with 2.75" mounting hole spacing.
3. Locate wires in outlet box. Connect all fixture wires to power supply wires: White to white, black to black, and green to green with wire nuts (Fig. 2).
DIMMING INSTALLATION refer to the 0-10V DIMMING INSTRUCTIONS.
4. After Connections push all wires and wire nuts inside junction box (Fig. 3).
5. Align fixture mounting slots with J Box mounting holes. USE 8-32 x 25 mm mounting screws (8-32 x 25 mm #8-32 machine screws) to secure fixture to J Box (Fig. 4).
Note: To ensure that once installed to the field junction box, there shall be no visible gaps between the ceiling surface at the outlet box and the luminaire housing.
In order to be more firm, 2-4 screws can be used to strengthen the fixture (Fig. 5).
6. Attach lens (Fig. 6) by aligning lens groove with edge of channel. Ensure lens groove is secured along entire length of the lens on both sides. Remove protective film from lens.
7. Turn breaker on. Use wall switch to verify light turns on.

**Head Office** - 1850 Wilson Ave. · Toronto, ON · M9M 1A1 · **Tel:** 416.741.7336 · **Fax:** 416.741.9104
**Toll Free:** in Canada. 1.800.661.9610 · in USA. 1.888.762.5384 (SOCKETS4U)
www.etlin-daniels.com · For sales/service questions - sales@etlin.com

# ETLIN-DANIELS

## INSTALLATION FOR WRA54S-M46W0C-WH LED WRAP AROUND LIGHT FIXTURE / CHANGEABLE WATTAGE AND COLOR TEMPERATURE




## SAVE THESE INSTRUCTIONS - READ ALL INSTRUCTIONS CAREFULLY

Intertek 5001780 · 5 YEAR LIMITED WARRANTY/GARANTIE LIMITÉE · CAN ICES-005 (B) / NMB-005 (B)

### WATTAGE & CCT SELECTION

The end users may adjust the color temperature and wattage,respectively, by the two slide switches integrated into the side of the fixture. Each switch has 3 options (left, middle and right ) each position corresponds to 1 of 3 color temperatures and 1 of 3 wattages, which can be adjusted to the desired combination.


1. Switches are located on the side of the fixture. (Fig.)
2. Select a wattage and color temperature by sliding switch left or right respectively to the desired value. (Fig.)





**Default Settings: 46W / 5000K**


### PENDANT MOUNT

Assemble the V Hanger and Chain as shown in the figure




How to assemble the chain






### 0 - 10V DIMMING INSTALLATION INSTRUCTIONS

**CAUTION:** Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
Universal voltage driver permits operation at 120V thru 347V, 50 or 60 Hz. 0-10V control wires must be rated for 300V minimum. For 0-10V Dimming, follow the wiring directions.

1. Connect the black fixture lead to the LINE supply lead.
2. Connect the white fixture lead to the COMMON supply lead.
3. Connect the green fixture lead to the supply ground).
4. Connect the violet fixture lead to the DIM(+) lead.
5. Connect the pink fixture lead to the DIM(-) lead.

### Wiring Diagram




**Head Office** - 1850 Wilson Ave. · Toronto, ON · M9M 1A1 · **Tel:** 416.741.7336 · **Fax:** 416.741.9104
**Toll Free:** in Canada. 1.800.661.9610 · in USA. 1.888.762.5384 (SOCKETS4U)
www.etlin-daniels.com · For sales/service questions - sales@etlin.com